



Step 1: Place 2 x U-bolts around frame of receiver



Step 2: Take the other 2 x U-bolts and place around end of receiver, insert them through the plate provided and secure them tightly with washer/nuts provided. Then secure plate to the U-bolts you previously put around your receiver frame with the washer/nuts provided



Step 3: Align pipes from KOMO frame to the new receivers installed and make sure to tighten all bolts. Insert into new receivers and install stabilizing clamps



Step 4: Install stabilizing clamp this way